


P721B Dining Table

Assembly Instructions

Two Person Assembly Required


Due to the weight of this base, must be assembled in upright position




HARDWARE PACKAGE

NO.	DESCRIPTION	Q'TY
Α	Flange Bolt 5/16" x 1"	4
В	Flat Washer	12
С	Wood Screw #8x1-1/2"	8
D	Rubber Glass Bumpers (used instead of Bolt A for glass tops only)	4

Step 1) Flip top upside down and lay on a carpet surface or blanket. Unscrew the base bridge from the top. Set the screws and washers to the side as they will be reused later to assemble base to top.



Step 2) Position the pedestal base in the desired location. Using provided bolts and washers, attach the bridge that was removed in step 1 to the base.



Step 3) Carefully flip the top to an upright position and center it onto the base (note the grain direction of the top). Using the provided screws and washers, screw through the holes into the bridge.

Repeat for the other 7 screws.