




VANGUARD®
FURNITURE

Thank you for your purchase of Vanguard Furniture.

CC20 & HH20 Series Lifestyle Cabinets

Assembly Instructions

Two Person Assembly Required





HARDWARE PACKAGE


NO.	DESCRIPTION	Q'TY
A	Wood Screw #8x1-1/4"	22
B	Mending Plate & Screws	4

1) Lay the cases on their back onto a soft surface, such as a blanket. Push the cases together.

2) Attach the base to the cases using the provided wood screws (A).




3) Using two people (one supporting each case), simultaneously lift the cases to the upright position.




4) Lay the top panel on the top of the cases so that it overlaps both cases and flush with the back edge.

5) On the back of the case, attach the top panel to the cases using the provided mending plates and screws (B). Make sure the top screw hits the top panel and the bottom screw hits the end panel. Repeat this step for the remaining three brackets.



**** Steps 6 and 7 are for Case Adjustments for Leveling ****

6) To adjust the gap between the cases, adjust the leveler (6A) in the Support Leg located under the gap between cases. Turn the leveler until the gap is even.



7) To adjust the outside case to be level, adjust the leveler (7A) in the Tapered Legs. Turn the leveler until the case is level.

NOTE: If you need to adjust the drawers or doors on your case, please refer to www.vanguardfurniture.com and click on Assembly Instructions link at the bottom of the home page for Instructions. Click on 'Adjustment and Leveling Instructions for Drawer Guides' for the drawers or 'European Hinge Adjustment Instructions' for the doors.