




VANGUARD°

FURNITURE




W221B Dining Table

Assembly Instructions

Two Person Assembly Required

HARDWARE PACKAGE

NO.	DESCRIPTION	Q'TY
Α	Wood Screw #8x1-1/4"	8
В	Rubber Glass Bumpers	4
	(used instead of screws	
	for glass tops only)	



- 1) Flip top upside down and lay on a carpet surface or blanket.
- 2) Remove the bridge as shown in Detail View A and throw away. It is not needed for this assembly.
- 3) Flip pedestal base upside down and align it on the center of the top (note the grain direction of the top).
- 4) Using the provided screws and washers, screw through the holes into the bridge. Repeat for the other 7 screws
- 5) Flip the assembled base and top back to the upright position.