VANGUARD

FURNITURE

8708T Dining Table

Assembly Instructions

Two Person Assembly Required

HARDWARE PACKAGE

NO.	DESCRIPTION	Q'TY
A	Hex Bolt 5/16" x 2"	8
B	Lock Washer	8
C	Flat Washer	8

1) Flip top upside down and lay on a carpet surface or blanket.

2) Flip a base assembly upside down and align it in the notches of the apron rail and on the blocks.

3) Using the provided screws, lock washers, and flat washers, screw through the holes into the blocks in 4 places. Repeat steps 2 and 3 for the other base assembly.

5) Flip the assembled base and top back to the upright position.